











One 3.5 mm headset jack

Permanent features keys



Quick access to the phone's main features



-  Interphony / Mute key.
-  Adjust audio volume.
-  Audio services (handsfree, handset or headset). Answer a call.
-  History and messages services.
-  History and messages services. Missed calls.
-  Activate or deactivate the virtual keyboard. Access the dial by name feature.
-  Open the device settings menu.
-  Homepage.

Bluetooth® handset








-  Off-hook/On-hook
-  Volume/Mute:
 - Short successive presses to change the handset volume level (3 levels).
 - Long press to activate or deactivate mute mode.

A sensitive LCD wide screen





Use the Up and Down arrows to go up or down on a page and show details not displayed on a single page.



- Menu page:** Contains all functions and applications accessible via the keys associated with the words on the screen.
- Perso page:** Contains call line keys (allowing supervision of calls) and programmable call keys.
- Info page:** Contains information on the telephone and the status of its functions: name, telephone number, number of messages, activation of transfer function, appointment reminder, etc.




-  Use this key to validate a choice, data entered, etc.
-  Use this key to go back to the previous step.
-  Use this key associated to the pads to switch from the dialpad to the alphapad.
-  Incoming call icon /Call in progress icon
-  Call holding icon



-  Long press: redialing the last number. Short press: call back one of the last 8 numbers dialed.
-  Messaging key to access various mail services: This key flashes when you have received a new voicemail, text message or callback request and is lit if you have missed calls. When not lit you can access various message services.
-  END key: to end a call or return to idle mode (the key is red when the line is taken or you are browsing through the menus).
-  Programmable keys (F1 and F2 keys): lit when the function associated with the key is activated. A service or a direct call can be associated to these keys.





Answer a call

Use one of the following:

- Lift the receiver
-  / 
- Select the "incoming call" icon  *Take call*


Call

Use one of the following:

- Dial directly the number for your call
-  Enter the name or initials or the surname and first name of your correspondent
-  /   Dial the number

Ignore call / End the call

Use one of the following:

- On hook
- 



Making a second call during a conversation

Use one of the following:



- *New call*
- Dial directly the number for your call
- Enter the name or initials or the surname and first name of your correspondent
- Redial key
- Programmed line key

To cancel your second call and recover the first:



Use one of the following:

- *Enquiry off*
-   You are in conversation with your first correspondent again

Answering a second call during a conversation

-   Line key for which icon is flashing
- *Take call*

Switching between calls (Broker call)

-   Select the contact on hold

Placing a call on hold (hold)

- *Hold (Common hold)*: To recover your call on any telephone in your system.
- *Put on hold*




Make calls via your programmed call keys

- **Perso page**
- Press the desired programmed call key






Program the keys for the Perso page or the add-on module

- **Perso page**
- Press the key you want to program
- Follow instructions given on display

Programming direct call keys (F1 and F2 keys)

-  Press a programmable key (F1 or F2)
- *Speed dial*  To program a number
- *My services*  To program a function
- Follow information displayed on the screen

Delete a programmed key

- **Menu page**  *Settings*  *Phone*  *Key program*  *Perso page*  *Keys*
- Select the key to delete
- *Delete*

Transferring a call

During a conversation

- Calling a second person during a conversation
- *Transfer*

Conference

During a conversation, a second call is on hold

- *Conference*

Sending DTMF signals

- *Send DTMF*
- Send numbers

Consulting your voice mailbox



Diverting calls to your voice mailbox

-   *Imm fwd to VM*

Canceling all diversions

-   *Deactivate*  *Deactivate forward*

Do not disturb

-   *Do not disturb*

Select the language of your choice

- **Menu page:**  *Settings*  *Phone*  *Language*

Choose the tune

- **Menu page:**  *Settings*  *Phone*  *Ringing*




Change password

- **Menu page:**  *Settings*  *Phone*  *Password*

Selecting the welcome page

- **Menu page:**  *Settings*  *Phone*  *Homepage*

Send text messages

-   *Text mail*  *Send*
- Enter the destination number
- Choose the type of message

Read text messages

The light indicates that messages have been received

-   *New text message*  *Read message*

Lock/unlock the phone

- **Menu page:**  *Lock / Unlock*