

# Alcatel-Lucent OmniPCX Enterprise

## Communication Server

### Functions and corresponding codes

If your telephone has neither the icon nor the corresponding key, the function is activated by entering the code.

Function	Code
3 party conference call	3
Associate call	
Attendant call	0
Broker call	1
Business account code	#9
Business account code prefix	
Call announcement	8
Call back request	5
Call from personal directory	
Camp on	
Camp on control	6
Cancel follow me	
Cancel overflow	
Cancel remote forward	*65
Cancel wake-up/appointment reminder	*81
Change associate number	#01
Charging meter readout	#3
Common hold	**0
Consult call back request	*68
Consult call on hold	*74
Consult voice mail	***
Contrast programming	*67
Direct call pickup	*72
Direct outside line	9
Direct paging call	*86
Do not disturb	*78
DTMF end to end dialing	#4
Enquiry call/Enquiry off	2
Forward cancellation	*64
Forward on busy or no reply	*63
Forward on no reply	*62
Group call pickup	*73
Identity display	**2
Immediate forward	*60
Immediate forward on busy	*61
Immediate overflow on busy	
Intrusion	4

Alcatel-Lucent Enterprise in keeping with its policy of constant product improvement for the customer, reserves the right to modify product specifications without prior notice.

# Alcatel-Lucent OmniPCX Enterprise

## Communication Server

Function	Code
Language	*84
Last caller call back	*69
Malicious call	
Meet me conference	**6
Night service answering	#8
Overflow on no reply	*66
Overflow on no reply and immediate overflow on busy	
Padlock	*77
Paging reply	
Paging request	
Park call/retrieve	*75
Password modification	**4
Personal directory programming	#5
Private call	
Protection against beeps	*87
Redial last number	*70
Remote forward	*88
Secret identity	**3
Select principal line	*82
Select secondary line	*83
Set group entry	**7
Set group exit	**8
Substitution	*76
Voice mail	##
Voice mail direct access	
Wake-up/appointment reminder	*80

Name: .....

Telephone No: .....