

Alcatel OmniPCX Enterprise

Functions and corresponding codes

If your telephone has neither the icon nor the corresponding key, the function is activated by entering the code.

Function	Code
3-party conference call	3
Associate call	
Associate number - change	#01
Attendant call	0
Barge-in	4
Broker call	1
Business account code	#9
Business account code prefix	
Call - using personal directory	
Call announcement	8
Call waiting - access	*74
Callback - set request	5
Callback requests - access	*68
Camp-on	
Camp-on control	6
Chargeback/Accounting reading	#3
Common hold	**0
Consultation call/consultation call off	2
Direct call pickup	*72
Direct outside line	9
Direct paging call	*86
Display - adjustment	*67
Do not disturb	*78
Follow me	
Follow me - cancel	
Forward on busy or no answer	*63
Forward on no answer	*62
Forwarding - cancel	*64
Forwarding - immediate	*60
Forwarding on busy - immediate	*61
Forwarding (remote)	*88
Forwarding (remote) - cancel	*65
Group call pickup	*73
Identity display	**2
Language	*84
Last caller call back	*69
Lock	*77
Manual hold	

Alcatel Business Systems in keeping with its policy of constant product improvement for the customer, reserves the right to modify product specifications without prior notice.



Alcatel OmniPCX Enterprise

Function	Code
Meet-me conference	**6
Night service answer	#8
Overflow on busy	
Overflow on busy - immediate	
Overflow on no answer	*66
Overflow on no answer and Overflow on busy - immediate	
Overflow - cancel	
Paging reply	
Paging request	
Park call/retrieve	*75
Password - change	**4
Personal directory - program	#5
Primary line - select	*82
Privacy/Protection against barge-in	*87
Private Call	
Redial last number	*70
Secondary line - select	*83
Secret identity	**3
Station group - entry	**7
Station group - exit	**8
Substitution	*76
Voice mail - access	***
Voice mail - direct access	
Wake-up/appointment reminder	*80
Wake-up/appointment reminder - cancel	*81

Name:

Telephone No:

