

Phone description



500 Ex DECT Handset

- 1
 - Off hook
- 2
 - Switch on / off
 - On hook
 - Return to first screen / return to previous menu
 - Switch off ringer
 - Activate/deactivate loudspeaker
 - Calls log ; (Redial)
 - Lock/unlock keypad (first press: Ok)
 - Apply
- 3
 - Access MENU : Message service , Personal directory , Settings menu items , Calls log
 - Erase a character
 - Apply
 - Navigate (up, down, left, right)
 - Affected shortcuts to the navigation keys (out of navigation use)
 - Activate/deactivate loudspeaker
 - Access your personal directory
 - Switch the screen on again
- 4
 - Access MENU : Message service , Personal directory , Settings menu items , Calls log
 - Erase a character
 - Apply
 - Navigate (up, down, left, right)
 - Affected shortcuts to the navigation keys (out of navigation use)
 - Activate/deactivate loudspeaker
 - Access your personal directory
 - Switch the screen on again
- 5
 - Access MENU : Message service , Personal directory , Settings menu items , Calls log
 - Erase a character
 - Apply
 - Navigate (up, down, left, right)
 - Affected shortcuts to the navigation keys (out of navigation use)
 - Activate/deactivate loudspeaker
 - Access your personal directory
 - Switch the screen on again
- 6
 - Silent mode (long press)
- 7
 - Microphone
- 8
 - Adjust audio volume
- 9
 - Red key : Alarm call (Option)
- 10
 - Headset socket
- LED
 - The LED settings depend on the configuration of the set (see Associate states of the handset to the LED colours)
- 11
 - The LED settings depend on the configuration of the set (see Associate states of the handset to the LED colours)
- 12
 - **Back-lit screen** The screen switches off automatically after a few seconds of inactivity. To turn it back on, press the key

Alcatel-Lucent 500 Ex DECT Handset is marked with the ATEX logo.

■ Access MENU

- Menu** Select a function in the MENU It provides access to all the functions available on your system.
- Select** Navigate in the menus and select the menu of your choice
- Messaging:** consult and send voice and text messages.
- Calls:** from the call log, select one of the last numbers dialed
- Contacts:** access your personal directory
- Calendar :** manage your appointments, your meetings , program a call-back time.
- Accessories:** access to the calculator, countdown or wake up features
- Settings:** adjust contrast, activate or deactivate the beeps, lighting, etc.

■ Call icons

- Incoming call
- Outgoing call
- Loudspeaker activated
- Silent mode activated (Loudspeaker vol)
- Silent mode activated (Microphone)

■ Charging your telephone battery



Connect the charger and place the telephone in the charging holder. The battery charger LED lights. The battery LED is in charging mode on the phone screen. The battery charging time is 6 hours.

Battery charge

	Battery fully charged (75% - 100%)
	Battery half charged ; (33% - 75%)
	Low battery (0% - 33%)
	Battery completely discharged (0%)

■ Switching your telephone on or off

- Long press

■ Status icons

- Battery charge level
- Radio reception quality
- Filtered calls
- Silent mode activated (ringer)
- Programmed call-back time
- Set is locked
- Missed calls

■ Features

The operation of your phone depends on its single or multi-line installation. For more information regarding this configuration, contact the person in charge of your installation. Which configuration is supported by your phone:

- 1 • Single-line set - Alcatel-Lucent OmniPCX Enterprise / Alcatel-Lucent OmniPCX Office
- 2 • Multiline set - Alcatel-Lucent OmniPCX Enterprise
- 3 • Multiline set - Alcatel-Lucent OmniPCX Office

Your system offers a wide range of services and features.

- To activate a feature when you are not in communication, take the set off the hook and enter the feature code followed by the parameters to associate to the feature
- To activate a feature while in communication, enter the feature code directly

For information on the features codes list, contact your installer or administrator. You can program a feature on a speed dial key by entering the feature code followed by parameters associated to the feature. Refer to chapter: Speed dial.

■ Making a call	
■ Receiving a call	
■ Switch off ringer	Silence
■ Reject call	Reject OR
■ Calling from your personal directory (Individual number)	Menu Select the name of the person you wish to call Quick access (by default) : Up navigation key
■ Programming your personal directory	Menu New contact Select the type of contact Add Select Enter the name , Enter the number Save Yes
■ Calls log	Call Select the desired log: all calls ,answered calls , answered calls , missed calls
■ Redialing	Select the recipient from the call log OR Call
■ Activate/deactivate voice frequency	Long press (During a conversation)
■ Speed dial	This feature allows you to associate a contact to a key on the keypad. Therefore, pressing and holding on this key will automatically start the call to the associated contact. This feature allows to associate a contact or a feature code to a key on the keypad. Pressing and holding on this key will automatically start the call to the contact or will activate the associated feature Menu select a directory entry More Speed dial Select
■ Activate/deactivate loudspeaker	Spk on / Spk off
■ Activate/deactivate the mute feature.	Mute / Unmute
■ Putting a caller on hold / Recover the correspondent on hold	This availability of this feature depends on your system and its configuration. Contact your installer to know which feature description must be used on your installation (see the table of supported configurations) 1 Enter the feature code 2 3
■ Make a second call	Dial directly number the first call is on hold Switching between two outgoing calls : 1 Enter the feature code 2 3

■ Receiving a second call	This availability of this feature depends on your system and its configuration. Contact your installer to know which feature description must be used on your installation (see the table of supported configurations) 1 Enter the feature code 2 Switching between two calls, either one or two incoming calls 3 Switching between two calls, either one or two incoming calls
■ Transferring a call (single-line terminal only)	You are in communication with a first correspondent Calling a second person during a conversation Hang up the ongoing call the two correspondents are connected
■ Setting up a conference (single-line terminal only)	You are in communication with a first correspondent. A second correspondent is on hold. Enter the feature code. Use the same procedure to cancel the conference and recover the first call.
■ Lock/unlock keypad	Lock / Unlock
■ Adjusting the audio functions / Activate the buzzer or the ringer	Menu
■ Selecting language	Menu Language Select
■ Set time and date	Menu Time & date Select Set time and date
■ Consulting your voice mailbox	Enter the feature code Follow the voice guide instructions
■ Enable Bluetooth	Menu Bluetooth Select Yes
■ Install a Bluetooth® device (pairing)	Before using a Bluetooth device with your phone, you must install the Bluetooth module in your phone. Your Bluetooth device is ready to be paired Menu Search for devices Select Select the Bluetooth device to be paired Select Ok

- Which configuration is supported by your phone:
- 1 • Single-line set - Alcatel-Lucent OmniPCX Enterprise / Alcatel-Lucent OmniPCX Office
 - 2 • Multiline set - Alcatel-Lucent OmniPCX Enterprise
 - 3 • Multiline set - Alcatel-Lucent OmniPCX Office

