




Phone description	
  	<p>1 A sensitive LCD wide screen.</p> <p>2 Permanent feature keys: quick access to the phone's main features.</p>  <p>Mute key.</p> <p>Turn down the volume.</p> <p>Turn up the volume.</p> <p>Pressing this key answers an incoming call in handsfree mode (the key is blue). When a call is in progress, pressing this key switches from handsfree mode to headset or handset mode.</p> <p>Pressing this key takes you to the routing menus.</p> <p>This key is lit when you have received a new voicemail, text message or callback request. When not lit you can access various message services. This key flashes if you have missed calls.</p> <p>Activate or deactivate the virtual keyboard.</p> <p>This key lights blue when there is a wake-up alarm.</p> <p>This key is used to return to the homepage at any time.</p>
	<p>3 A Bluetooth® handset for optimized communication. A wired handset is also available and can replace the Bluetooth® handset.</p>
	<p>4 A wideband loudspeaker for optimized sound.</p>
	<p>5 LED Arrival of a new call (Flashing).</p>
	<p>6 An adjustable and stable foot.</p>
	<p>7 One 3.5 mm headset jack</p>
	<p>8 Various connections to allow phone extensions.</p>
	<ul style="list-style-type: none"> <li>Add-on module connector (SATA type). 2 USB connectors for video or USB storage device.</li> <li>1 mini-USB connector for a keyboard(1).</li> <li>Two 10/100/1000 Mbps Ethernet connectors to enterprise network (LAN) and a PC. One DC power jack for an external power adaptor.</li> <li>1 RJ9 connector for a corded handset.</li> </ul> <p>(1) For future use.</p>

Bluetooth® wireless handset		
	<p>Off-hook/On-hook.</p>	
	<p>Volume/Mute:</p> <ul style="list-style-type: none"> <li>Short successive presses to change the handset volume level (3 levels),</li> <li>Long press to ensure your correspondent no longer hears you.</li> </ul>	



Homepage in standard mode

Homepage in standard mode

About the homepage	
1	<p><b>Personal area</b> This area displays information about the user's phone and configuration, including last name, first name, avatar, and routing.</p>
2	<p><b>Notifications area</b> In idle state: This area displays information on the latest phone events, such as missed calls and voice messages. During a call: Call status (ongoing, on hold, incoming call) is shown in this area. Pressing this area during a call takes you back to the call screen.</p>
3	<p><b>Date, time and connectivity area</b> This area displays time, date, connectivity and customization information (wake-up on, intercom mode on).</p>
4	<p><b>Active area</b> This area is reserved for running applications and for previews of applications selected by the user. When you start an application, it is displayed in the active zone. If no application has been launched, the active zone displays the application previews that you have preset on the homepage. One application preview allows you to view this application information and easily access it. Applications that can be previewed are: History, Favorites, Manager/Assistant.</p>
5	<p><b>Applications bar (Homepage in advanced mode)</b> This area allows access to all set applications and to different features of the running application.</p>
6	<p><b>Applications area (Homepage in standard mode)</b> You can access your phone applications from this area. Press the application button to access the application. Programmable keys are available in this mode. Once you run an application, the display is the same as the preview mode display.</p>

Homepage	
The phone set homepage can be viewed in standard or advanced mode. Scroll your finger up or down to get the page or menus scrolling vertically (in advanced mode), or scroll right or left to get the page scrolling horizontally. (in standard mode only).	
Make your selection by pressing on the screen.	
Access the Advanced Homepage mode.	
First press: back to the previous homepage page. Second press: back to the first homepage page.	
Go to next screen. Back to previous screen.	
Scroll through the application area pages (standard mode) or the application bar (advanced mode) to find the application you want.	
Press the application button to access to the application.	
In standard mode only, you can have up to 6 pages. In standard mode, homepages are for applications and programmable keys. Two types of icons are displayed at the bottom of the page :	
Symbolizes the first page (Homepage).	
Symbolizes extra pages (empty circle). When this icon is full, it means that you are currently viewing the page. This helps you to know which page you are on when navigating through the different pages.	

Call status			
	Incoming call.		Video active on your phone (blue color).
	Ongoing call.		Video available on your phone (white color).
	Call on hold.		Your phone is a supervisor phone or is supervised.
	Three-party conference.		

Function icons	
	Make a call.
	Search for a correspondent by name.
	Access the handset settings menu.
	This application allows you to manage audio files and images.
	The history application shows two tabs, listing new phone events such as missed calls, and older phone events.

	To access voice mail functions.
	This application contains favorite contacts that you have selected from your list of contacts. Call a contact from the favorites application.
	Make a call using your list of contacts.
	Lock / unlock your telephone.
	This application is for synchronizing your address book and agenda between your phone and your PC Outlook application.
	Set an alarm.
	Access the Advanced Homepage mode.

Keys appearing when in communication	
	Start a video call.
	End an ongoing communication.
	Access the DTMF feature and activate DTMF signals. You might need to send DTMF signals when you are in communication with a call server for example.
	Initiate a second call. The first call will be on hold as soon as the second correspondent's number is dialed. Once your second correspondent is on the line and the first correspondent is on hold, you can transfer the ongoing call to the correspondent on hold or you can start a conference.
	This key appears when you initiate a second call or when you are in conversation with a second correspondent. When pressing on this key, the second call is transferred to the call on hold.
	This key appears when you are in conversation with a second correspondent. Press on this key to start a conference with the correspondent on hold and the second correspondent.
	Add participant.
	Remove participant.
	End the ongoing conference.
	Put a correspondent on hold.
	Retrieve the correspondent on hold.
	Record the ongoing conversation. The recording is stored in the voicemails menu. Pause the recording of the current conversation. Resume the recording of the conversation.

Keys dedicated to specific features	
Some keys appear only when certain features are accessed.	
	Call back the selected correspondent in the call log.
	Add the selected correspondent in your list of contacts.
	Delete the selected item of the call log.
	Delete the complete call log.
	
	Call a selected contact.
	Search for a contact in the Company's directory.
	Search for a contact in the Company's directory. Add a selected contact in your list of Favorites.
	Add a contact to your list of contacts.
	When you want to add a searched contact to the list of contacts, press on the card details.
	Edit the details of a contact.
	Delete a contact from your list of contacts.
	
	All new messages.
	Old messages.
	Listen to message.
	Pause while listening to message.
	Stop listening.